

POLANIK
Poland, Życzliwa 11
97-300 Piotrków Trybunalski

tel. +48 44 646 44 81
tel. +48 44 648 50 89
fax +48 44 646 43 58

e-mail: info@polanik.com
www.polanik.com



INSTRUCTION MANUAL

High jump club landing area monocube

W-636-B



File: 2014-07-17

PRODUCT SUPPORT
Paweł Ciechanowski
p.ciechanowski@polanik.com

Thank you for choosing POLANIK landing area.

Safe assembly and use

- **ATTENTION! VACCU M PACKED PRODUCT – UNPACK IMMEDIATELY AFTER DELIVERY**
- Before you start to assemble and use the landing area please read this manual carefully and store the manual in a safe place for further reference. Polanik Sp. z o. o. – Sp. K. shall not be liable for any cage damages which are the result of the failure to follow this manual.
- Unauthorized copying of this manual, in whole or in part, is prohibited.
- The contents of this manual are subject to change without notice.
- Warning! The sports equipment produced by Polanik Sp. z o. o. – Sp. K. is designed for athletics training and use in sports competitions only. Please pay special attention when using the product, misuse of athletics equipment can cause serious injury or in extreme cases even death. That is why training and use during sports events have to be always supervised by authorized sports personnel. In no event shall Polanik Sp. z o. o. – Sp. K. be liable for any special, incidental, indirect or consequential damages in connection with the purchase or use of POLANIK products or costs over the original cost of the product.
- Specific warranty terms:
 - 1) The use of the landing area outdoors requires a waterproof cover and a landing area platform for proper insulation from the ground. Failure to follow the above restrictions results in the loss of the warranty rights.
 - 2) The top pad of the landing area is equipped with a spike resistant mesh fabric. The mesh fabric is designed to protect the landing area against spikes used by jumpers. While landing and walking on the top pad the spikes go through the mesh fabric and do not damage the surface. One must not shuffle the spikes on the mesh fabric, because under high crosswise stress caused by moving the spikes without lifting the feet, it may happen that the top pad will be torn. The damages of the top pad caused by careless sliding the pikes on the top pad surface are excluded from the warranty and can be removed in course of payable repair or replacement of the landing area elements.

Contents

Chapter	Page
I. General description	3
II. Technical specification	3
III. Preparing for first use	3
IV. Assembly	3
V. Operating	4
VI. Maintenance	4
VII. Storing	4
VIII. Declarations and certificates	5

I. General description

POLANIK landing area W-636-B is top quality sports equipment which is designed to secure jumpers and absorb impact energy of a jumper's landing after take off and flight in high jump training.

II. Technical specification

Code	W-636-B
Dimensions length / width / height [m]	6 / 3 / 0,6
Weight [kg]	218
Foam units	3 pcs, advanced 3-layer construction, made of high quality PUR foam, overlapped to eliminate empty spaces between units
PVC master covering	made of polyester with two vinyl layers, upper surface is equipped with spike resistant mesh fabric, zipper closure
Way of waterproof cover linking	Velcro® belts

III. Preparing for first use

The landing area foam units are vacuum packed only for transport. Please unpack them immediately after delivery and leave them in a roofed place for few hours, so that they can return to their original shapes. **Storing vacuum packed foam units may cause permanent damages in their structures.** Please keep the plastic transport bags for future use.

When the units return to their original dimensions, you can place them in high jump field. The field surface should be even, smooth and without any obstacles. If you use the landing area outdoors, you should also provide: a special waterproof cover P-636-B to protect the landing area against unfavourable weather conditions and a modular platform SW-6x3 to insulate the landing area from the ground.

IV. Assembly

It is done in 4 easy steps:

1




place the PVC master covering on the surface where the landing area is to be situated,

2



then put the first foam unit onto the covering,

3



next put the other unit onto the covering, so that it overlaps the first one, do the same with next one.

4



then cover the units and zip the master covering. The landing area is ready for use.

V. Operating

Stepping on the landing area and practising require special footwear designed for those purposes. Treading on the landing area in footwear with spikes is only allowed when the landing area is equipped with special spike resistant surface. Stepping on the landing areas in hard footwear or in shoes with heels is strongly prohibited. You must not put any tables, chairs, benches or any other objects whose unit pressure exceeds $1\text{kg}/1\text{cm}^2$ on the landing area.

Please note that the foam units are not designed to be taken from the PVC master covering. Since the units have not got their own coverings, the foam is vulnerable to damages when you remove the units from the PVC master covering. Therefore if you are forced to remove them from the master covering, please do that carefully and store the units in their transport plastic bags.

VI. Maintenance

Due to the hygiene requirements it is recommended that the landing area should be cleaned regularly with commonly available detergents. Before you start wiping the landing area, please try to clean a small spot on its bottom side in order to check the reaction with the PVC fabric.

VII. Storing

The landing area can be stored only in a horizontal position. It cannot be bent or pressed by any objects during storing. That may deform it permanently. A storing facility should be clean and dry. It ought to provide min. temperature $5\text{ }^{\circ}\text{C}$.

Even the best technical solutions cannot substitute for common sense. The usage of the product must take place under the supervision of qualified coaches. The producer shall not be liable for any incidents caused by the improper assembly or its misuse. The producer reserves the right to introduce without warning changes in product constructions and colours.

VIII. Declaration of conformity

- 1) No. 2013-10-29
- 2) Issuer's name: POLANIK Sp. z o. o. – Sp. K.
Issuer's address: Życzliwa 11, 97-300 Piotrkow Tryb.
- 3) Object of declaration:

Position	Description	Code
1	High jump club landing area monocube 6 x 3 x 0,6 m	W-636-B

- 4) The object of declaration described above is in conformity with the requirements of the following documents:

Document No.	Title	Edition/Date of issue	Position
PN-EN 12503-2	Sports mats – Part 2: Pole vault and high jump mats, safety requirements	April 2004	All above

Additional Information

- 5) Declaration for:
BUYER and USER

Signed for and in behalf of:

POLANIK

2014-07-17 Piotrkow Tryb.
(Date and place of issue)

Pawel Ciechanowski
Product Manager

- 6)
(Name, function)



.....
(Signature or equivalent authorized by the issuer)